

Kit Includes

- Front Bumper (6) 1/2" NC Thread 1 1/2" Long Grade 8 Bolts. (4) For Top of Front Bumper (2) For Bottom of Front Bumper



- Front Shackle Hanger Bolts and Steering box bolts (7) 7/16" NC Thread 1 1/2" Long Grade 8 Bolts. (4) For Front Shackle Hanger. (3) For Steering Box. NOTE : If Heavy Duty Steering Box Bracket was ordered there will be double of some bolts due to Hardware Kit that comes with Heavy Duty Steering Box Bracket



- Front Sway Bar Bolts (2) 1/2" NC Thread 3 1/2" Long Grade 8 Bolts, (2) 1/2" NC Grade 8 Bolts.



- Skid Plate Transmission Crossmember Bolts (10) 3/8" NC Thread 1" Long Bolts. (6) For Skid Plate. (4) For Front Sway Bar.



- Bump Stop Bolts (8) 5/16" NC Thread 1" Long Bolts. NOTE : Also used for Front Gas Tank Bolts, and Front Brake Line Tab Holder Bolts



- Front Brake Line Holder (4) 5/16" NC Thread 1" Long Bolts
- Front Gas Tank Bolts (3) 5/16" NC Thread 1" Long Bolt, (8) 5/16" NC Thread Nuts for Front and Rear Gas Tank Bolts



- Rear Gas Tank Push Nut (5) 5/16" Push Nut/Speed Nut to Lock Rear Gas Tank Carriage Bolts



- Rear Gas Tank Bolts (5) 5/16" NC Thread 1" Long Carriage Bolts



- 1976-1981 CJ5/7/8 (12) 3/8" NC Thread 3" Long Bolts (12) 3/8" Lock Nuts (12) 3/8" Flat Washer. All for Motor Mount Bolts, and Shock Mount Bolts.
- 1982-1986 CJ5/7/8 (18) 3/8" NC Thread 3" Long Bolts (18) 3/8" Lock Nuts (18) 3/8" Flat Washer. All for Motor Mount Bolts, and Shock Mount Bolts.



- Use Lock Tight when installing bolts
- You might want to run a tap or thread chaser through nuts before install new bolts