



www.ThrottleDownKustoms.com

CJ8 Overland Tank



Our CJ8 Overland Tank is designed specifically for our CJ8 Frames. However, it will fit in 1982-1986 CJ8 Factory Frames with slight modifications.

If you are installing it in a Factory Frame you will need to remove your Factory Rear Tank Crossmember and weld in the supplied Rear Tank Crossmember. It will need to be welded 10 $\frac{3}{4}$ " inches from Back of Frame to Center of new Crossmember.



We also supply a new Rear Tank Strip that may or may not need to be welded into your Factory Frame.



Included with our CJ8 Overland Tank :

1 – Replacement Rear Tank Crossmember

1 – Replacement Rear Tank Strip

3 – 5/16" NC Thread 1" Long Bolts

8 – 5/16" NC Thread Nuts

5 – 5/16" Push Nuts / Speed Nuts

5 – 5/16" NC Thread 1" Long Carriage Bolts